

1. What you will need:



Cisco 7940/7960 Phone
Provided



Power Supply
Provided



Network Cable
One provided in box. Will need one additional to connect to Computer



Power Outlet



Network Jack

2. Unpack Phone:

Plug one end of spiral phone cord into bottom of handset. Plug other end into the port on the back of the phone that has a handset icon. (Number 6 in Figure A-1)

3. Plug into Outlet:

Plug power supply into port shown as 1 in Figure A-1. Plug into power outlet.

4. Connect to Network Jack

Use one network cable. Plug one end into network jack on wall and the other into 10/100 SW (4 in Figure A-1.)

5. Connect to Computer

Use second network cable. Plug one end into network jack on computer and the other end into port 10/100 PC (Number 5 in Figure A-1.)

6. Connected!

If you see your phone number and display on the phone, it is successfully connected. If you don't, then you may have a problem. Refer to our online help guide @ www.virtualphonesystem.ca or contact us directly at (905) 855-0533 also feel free to use our online live support system.

Figure: A-1

